



ACCEL BRK/IN TEST AREA
DRIVER CHANGE AREA

DRIVER REST AREA

START/FINISH